



BORÅSTAPETER

WALLPAPER MADE IN SWEDEN SINCE 1905

Appliceringsinstruktioner

DU BEHÖVER:

Sprayflaska
Flytande tvål


Skrapa
Pappershanddukar

Fönsterputs
Måttband

Vass mattniv
Linjal




RENGÖR GLASET. Rengör fönstret noggrant. Använd vid behov ett rakblad. Boråstapeters fönsterfilmer fäster på rent, slätt glas eller plexiglas. Filmen fäster inte på frostat eller strukturerat glas, väggar eller andra fönsterfilmer.



MÄT FÖNSTRET / TRIMMA FILMEN. Det måste finnas en glipa på ca 1,5 mm mellan filmen och fönsterkarmen (innanför gummilisten). Markera och skär direkt i filmen medan den fortfarande sitter på pappersbaksidan, med linjal/rak kant och en vass mattniv. För fönster med udda form: gör en pappersmall, rita av och skär ut.



BLÖT GLASET. Tillsätt ett par droppar flytande tvål i en sprayflaska med varmt vatten och spraya så att fönstret blir ordentligt blött. Generösa mängder av tvållösningen gör monteringen enklare och mer lyckad. Det är mycket viktigt att inte blöta pappersbaksidan medan den sitter kvar på filmen.



TA BORT BAKSIDAN. Dra loss filmen från pappersbaksidan med början i ett hörn. Skydda filmen från smuts och skräp. Om filmen råkar klibba mot sig själv, separera den försiktigt.



APPLICERA FILMEN. Placera den blanka sidan av filmen (den sida som låg mot pappersbaksidan) mot det väl blöta glaset och justera den på plats. Använd inga lim eller andra fästmedel – filmen sitter kvar på glaset tills den tas bort. Låt inte filmen komma i kontakt med fönsterkarmen eller gummilisten.



SKRAPA. Spraya utsidan av filmen med samma tvållösning. Börja i mitten och använd skrapan för att trycka ut alla luftbubblor och vatten. Om bubblor finns kvar, gnugga ut dem mot närmaste kant med en pappershandduk. När monteringen är klar: torika bort kvarvarande vatten med pappershandduk eller en mjuk trasa.

YTTERLIGARE ANMÄRKNINGAR:

För att säkerställa att produkten fäster rekommenderar vi att utomhustemperaturen är över ca 4°C vid applicering.

Boråstapeters fönsterfilmer kan sättas ihop kant i kant om fabriksskurna kanter matchas (uppifrån och ned eller sida vid sida). Varje ark är en hel mönsterrapport. Vid applicering: skrapa mot skarven.

Rekommenderas inte för användning i armaturer eller nära någon artificiell värmekälla.

Filmen kan rengöras med valfritt mildt fönsterputsmedel.

Produkten är avsedd för dekor och för att ge insynskydd. Som alla färgpigment kan den med tiden blekna.

Vissa fönstertillverkares garantier kan upphöra att gälla om fönsterfilm appliceras. Fönsterfilm spräcker inte glas, men kan avslöja eller påskynda en inneboende defekt i glaset. Glasbrott är sällsynta.

VARNING. Förvara alla plastfilmer utom räckhåll för små barn.



BORÅSTAPETER

WALLPAPER MADE IN SWEDEN SINCE 1905

Application Instructions

YOU WILL NEED:

Spray Bottle
Liquid Soap


Squeegee
Paper Towels

Window Cleaner
Measuring Tape

Sharp Utility Knife
Straight Edge




CLEAN GLASS. Thoroughly clean window, using a razor blade if necessary. Boråstapeter films will adhere to a clean smooth glass or plexiglass surface. The film will not adhere to frosted, textured glass, walls or other window films.



MEASURE WINDOW / TRIM FILM. It is necessary that a 1,5 mm gap exists between the film and the window frame (inside the gasket). Mark and trim directly on the film while on paper backing using a straight edge and a sharp utility knife. For odd shaped windows make a paper pattern then trace and cut.



WET GLASS. Add a couple drops of liquid soap to a spray bottle with warm water and saturate window. Applying generous amounts of the soapy solution will make the installation process easier & more successful. It is very important to not get the paper backing wet while on the film.



REMOVE BACKING. Remove film from the paper backing starting in the corner. Protect the film from any debris. If film comes in contact with itself, carefully separate.



APPLY FILM. Place the shiny side of the film that was facing the paper backing onto the well saturated glass and position into place. Do not use any adhesives when applying, the film will remain on the glass until removed. Do not allow the film to touch the window frame or gasket.



SQUEEGEE. Spray the outside of the film with same soapy water mixture. Starting from the center, use a squeegee to move out all air bubbles and water. If any bubbles remain, rub out to the nearest edge with a paper towel. When finished installing, clean up any remaining water with a paper towel or soft cloth.

ADDITIONAL NOTES:

To assure the product adheres to window, we recommend the outside temperature be above 4°C for the application process.

Boråstapeter films will tile together when factory edges are matched top to bottom or side to side. Each sheet is one full repeat. During application, squeegee towards the seam.

Not recommended for use in light fixtures or near any artificial heat source.

Film can be cleaned using any mild household window cleaner.

This product is intended for decorative purposes and to provide privacy. As with all color pigments it may, in time, fade.

Some window manufacturers' warranties are void when window film is applied. Window film does not break glass. However, it can reveal or accelerate an inherent defect that is in the glass. Occurrences of breakage are rare.

WARNING: Please keep all plastic films away from young children.